
# **ASSEMBLY INSTRUCTIONS** FOR ADJUSTABLE FLAT PANEL WALL MOUNT

This product is designed to mount LCD TV weighing up to 30kg to wall.

Safety Warning: Be careful to make sure there are no missing or defective parts. Never use defective parts. Improper installation may cause damage or serious injury.

Note: The included hardware is for mounting on solid brick, concrete or hard wood batten/studs walls . If mounting on wood, do not use any concrete ancher. If you are uncertain about the nature of your wall, consult an expert. Please consult your hardware or installation professional for proper mounting to other types or walls. The supplied hardware is

Forbidden Instruction: Do not mount onto plasterboard or paneled walls.







## **FIX TO WALL**

Note: This product should be mounted to solid brick, concrete or hard wood batten/studs wall.

#### (a) SOLID BRICK AND CONCRETE BLOCK MOUNTING:

Use the wall plate as a template to mark 6 holes locations on the wall. Pre-Drill these holes with a 8mm masonry bit to at least 60mm in depth. Insert a Concrete Anchor@into each of these holes, Attach the wall Plate to the wall using 6 Lag bolts D









#### (b) HARD WOOD WALL MOUNTING:

Use the wall plate as a template to mark 6 holes locations on the wall. If the bracket mount onto wood studs wall. please use a high quality stud sensor to locate adjacent stud. It is a good idea to verify whether the holes you mark in the centre of the stud. Attach the wall Plate to the wall using for the 6 Lag Bolts D

Note: Do not use any concrete ancher when you mount the bracket onto hard wood wall.





### **TENDING INSTRUCTION**

Please check whether screws are fixed well each two months.

IF YOU HAVE ANY DOUBTS REGARDING INSTALLATION CONSULT OUR SPECIAL FRANCHISER.